
0


1



1/3

F/G. 1

20



71G. 2

DOD IS INSERTED INTO HOST. BOTH POD AND HOST GO THROUGH INITIALIZATION 000 PHASE TO SET UP HOST/ POD INTERFACE HOST CREATES TWO TRANSPORT CONNECTIONS 102 OVER COMMAND AND DATA CHANNELS, FOR SENDING TRANSPORT PACKETS OVER THE CHANNELS 104 HOST STARTS A SMART AGENT MANAGER APPLICATION SENDS A MESSAGE OVER THE COMMAND 106 CHANNEL TO THE SMAPT AGENT MANAGER, REQUESTING DOWNLOAD OF A SMART AGENT 108 SMART AGENT MANAGER "PULLS" SMART AGENT FROM POD THROUGH DATA CHANNEL, PLACES IT IN HOST MEMORY, AND STARTS IT 110 SMA-FT AGENT SENDS MESSAGE TO ITS APPLICATION IN THE POD, INDICATING THAT IT IS PEADY TO 112 APPLICATION AND SMART AGENT COMMUNICATE WITH EACH OTHER VIA DATA AND COMMAND CHANNELS

F16.3